# White Paper





### Thermal and Ignition Barriers for Spray Foam Insulation

The building code regulations regarding spray foam insulation and coatings can be tricky if you aren't familiar with the requirements. However, understanding the background and the intent behind the regulations will help you understand how best to approach your specific building needs.

Chapter 26 of the International Building Code addresses the use of Foam Plastic Insulation.
Section 2603.3 – unless otherwise indicated in this section, foam plastic insulation and foam plastic cores of manufactured assemblies shall have a flame spread index of not more than 75 and a smoke developed index of not more than 450 where tested in the maximum thickness intended for use in accordance with ASTM E 84 or UL 723. Loose fill-type foam plastic insulation shall be tested as board stock for the flame spread and smoke-developed indexes.

This section sets limits on the flame spread index as well as the smoke-developed index. Under the ASTM E 84 standard, only class A and B ratings are acceptable. Today, many commercial foam plastics have achieved these ratings. The key distinguishing factor between these ratings is the allowable flame spread rating for Class A is 25 and for Class B is 75. The smoke development index is the same for both ratings. You may notice that the smoke development index is also relatively high at 450 compared with other insulation materials.

In building fires, smoke inhalation and asphyxiation are the two main causes of fatalities. It is for this reason that foam plastics are held to a higher standard in the building codes than many other products. Many of the stipulations placed on spray foam often seem illogical or overly cumbersome. However, when these regulations are followed foam plastic insulation systems can be safer than traditional insulation systems. These regulations have challenged the foam plastic industry to create better building products.

### **Prescriptive Thermal Barriers**

The key with any foam plastic insulation, be it spray foam or rigid foam board, is to always protect the occupants from the foam in the event of a fire. The main way this is accomplished is by using building materials that are considered thermal barriers. The International Building Code states that foam plastics must be separated from the occupants by a 15-minute thermal barrier.

Section 2603.4 Thermal Barrier: Except as provided in sections 2603.4.1 and 2603.9, foam plastic shall be separated from the interior of a building by an approved thermal barrier of 0.5 inch gypsum wallboard or equivalent thermal barrier material that will limit the average temperature rise of the unexposed surface to not more that 250°F after 15 minutes of exposure, complying with the time temperature curve of ASTM E -119. The thermal barrier shall be installed in such a manner that it will remain in place for 15 minutes based on FM4880, UL 1040, NFPA 286, or UL 1715. Combustible concealed spaces shall comply with Section 717. Based on this code section, gypsum wallboard is commonly referred to as a prescriptive thermal barrier. However, other products can be used as prescriptive thermal barriers if they have successfully passed ASTM E 119 as outlined in 2603.4. Some of these products include <sup>3</sup>/<sub>4</sub>" OSB/Plywood, URE-K from International Cellulose and Monokote-3306 by Grace Construction Products.

#### **Prescriptive Ignition Barriers**

In some cases, which are outlined in IBC 2603.4.1, a thermal barrier is not required as long as an ignition barrier is used. Thermal barriers essentially provide a timed rating, ensuring that occupants have at least 15 minutes after fire exposure before foam plastics become involved in the fire. Ignition barriers do not offer a timed rating. The purpose of ignition barriers is to impede the direct contact of a flame to the foamed plastic insulation. When the model codes were first developed, several common building materials were listed as prescriptive ignition barriers. These include 1½" mineral fiber or fiberglass, ¼" plywood, ¾" gypsum wall board, or corrosion resistant steel with a base metal thickness of 0.016 which is approximately 28-30 Gage.

The most common exception issue faced by most spray foam contractors is in attics and crawlspaces. Under IBC 2603.4.1.6, attics or crawlspaces where entry is only for the service of utilities do not require a thermal barrier, but do require an ignition barrier. The key here is that the foam is still separated from the occupants by a thermal barrier (i.e. the ceiling), but the area inside the attic or crawlspace doesn't need the same level of protection since no occupants will enter this space for any extended period of time. It is however necessary to make sure that if a fire starts in this space, it doesn't spread rapidly. Ignition barriers provide this protection.

### **Non-Prescriptive Thermal Barriers**

In addition to the prescriptive thermal barriers that have been discussed, there are test methods that can be used to identify non-prescriptive thermal barriers or approved assemblies. All special approvals (including thermal and ignition barriers) have their roots in the special approvals section of IBC 2603.9. This section basically states that if you want to avoid using a prescriptive thermal or ignition barrier, then the spray foam assembly can be tested. If the assembly is proven to be "safe" then that alternative thermal/ignition barrier can be used or a foamed plastic can be approved without any covering.

Special Approval. Foam plastic shall not be required to comply with the requirements of Sections 2603.4 through 2603.7 where specifically approved based on large-scale tests such as, but not limited to, NFPA 286 (with the acceptance criteria of Section 803.2), FM 4880, UL 1040 or UL 1715. Such testing shall be related to the actual end-use configuration and be performed on the finished manufactured foam plastic assembly in the maximum thickness intended for use. Foam plastics that are used as interior finish on the basis of special tests shall also conform to the flame spread requirements of Chapter 8. Assemblies tested shall include seams, joints and other typical details used in the installation of the assembly and shall be tested in the manner intended for use.

Note that the specific assembly must be tested. ASTM E 119 tests the fire resistance of the covering whereas the large-scale tests look at the full assembly. This means that a non-prescriptive thermal barrier which is applied to brand X foam and successfully passes a test that complies with one of the test methods listed 2603.9 is not also approved over brand Y foam. This non-prescriptive thermal barrier would also have to be applied to brand Y foam and then that assembly will undergo the same test procedure.

#### **Non-prescriptive Ignition Barriers**

The tests indicated in IBC 2603.9 are all test methods used to examine thermal barriers. When the building codes

were written, there were and still are no small-scale test methods which can be used to approve non-prescriptive ignition barriers. Products must be tested using a modified NFPA 286 test as outlined in ICC-ES AC-377 Appendix X.

The good news is that the treatment options and the conditions of use for foam plastic insulation have been simplified. This will result in lower liability due to improperly applied products and confusion among builders, architects, code officials and contractors. Building owners and occupants will benefit from the increased safety provided by these more stringent building codes.

Based on the changes to ICC-ES AC-377<sup>1</sup>, Rhino Linings Corporation updated its recommendations for use of BioBased Insulation<sup>®</sup> and DuraTite<sup>®</sup> products within attics and crawlspaces. These new changes are reflected in an updated ICC-ES report and product Technical Data Sheets for all Rhino Linings spray foam insulation products and are summarized here for our most popular products.

#### **BioBased 501w®**

BioBased 501w is a 0.5 lb density open cell, spray polyurethane foam. When installed in applications that need a thermal barrier, BioBased 501w can be used with a standard ½" gypsum prescriptive thermal barrier. However, this product can also be covered with 30 wet mils/18.3 dry mils of Flame Seal TB or 18 wet mils/12 dry mils of DC315. These are intumescent paint products that has been tested with BioBased 501w in a UL 1715 test as identified in IBC 2603.9.

In addition to the prescriptive ignition barriers previously discussed, Flame Seal TB and DC315 have been approved as an non-prescriptive ignition barrier over BioBased 501w. As an ignition barrier, DC315 or Flame Seal TB must be applied at 4 wet mils/3 mils.

### DuraTite<sup>®</sup> 2.0

In some cases, closed cell foam insulation products are desirable because of their increased R-value where the assembly thickness is limited. In addition, closed cell foams can act as a Class II vapor retarder at a depth of approximately 1.5".

DuraTite 2.0 is Rhino Linings 2.0 lb density, closed cell spray foam insulation. This 245fa-blown insualtion has passed the modified NFPA 286 test as designated in ICC-ES AC377, Appendix X without any coverings. This allows the product to be installed in applications that require a prescriptive ignition barrier without any coverings. However, DuraTite 2.0 does require a thermal barrier in areas that will be exposed to building occupants. In lieu of a prescribed 15-minute thermal barrier, DC315 is an apporved non-prescriptive thermal barrier. It must be installed at 20 wet mils/14 dry mils.

### **Additional Details**

CADDs which detail various wall and roof assemblies using both BioBased 501w° and DuraTite° 2.0 have been included in Appendix A. In addition, there are three design considerations to keep in mind:

1) Rhino does not recommend nor endorse open combustion appliances located within a conditioned attic or crawlspace assembly. These types of appliances are less energy efficient than their closed combustion cousins

<sup>&</sup>lt;sup>1</sup> Acceptance Criteria for Spray-Applied Plastic Insulation AC-377, ICC Evaluation Services, Inc., Effective Date November 1, 2010

and in some cases can present significant safety hazards. If these appliances are used, we recommend locating them within a mechanical closet with combustion air supplied in accordance with IMC Chapter 7. The direct combustion air supply from outside is mandatory.

- 2) In its strictest interpretation, an attic or crawlspace area with storage for household items will be used for access other than "the service of utilities" as defined by IRC 315 and IBC chapter 26. Therefore foam plastics located with the "storage" area of an attic must be protected by a 15-minute thermal barrier. In this instance, the application of Flame Seal TB or DC315 at the appropriate thickness may be the best course of action instead of <sup>1</sup>/<sub>2</sub>" gypsum wall board.
- 3) When using an intumescent coating, especially as a thermal barrier in occupied spaces, it is important to protect the coating. Coatings can be damaged or punctured by bumps. In areas where damage may occur some type of impact resistant protection must be provided, or a prescriptive thermal/ignition barrier should be used.

#### **About The Author**

Cam Shafer is the building science and technical manager for Rhino Linings Corporation.

If you'd like to include BioBased Insulation<sup>®</sup> or DuraTite<sup>®</sup> in your architectural reference library, a complete architectural manual is available for free from Rhino by e-mailing your request and mailing address to sales@rhinolinings.com.









## NON-VENTED ATTIC DETAIL - CLOSED CELL



NOTES:

- 1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
- 2. DO NOT SCALE DRAWING.
- 3. THIS DRAWING IS INTENDED FOR USE BY ARCHITECTS, ENGINEERS, CONTRACTORS, CONSULTANTS AND DESIGN PROFESSIONALS FOR PLANNING PURPOSES ONLY. THIS DRAWING MAY NOT BE USED FOR CONSTRUCTION.
- 4. ALL INFORMATION CONTAINED HEREIN WAS CURRENT AT THE TIME OF DEVELOPMENT BUT MUST BE REVIEWED AND APPROVED BY THE PRODUCT MANUFACTURER TO BE CONSIDERED ACCURATE.
- 5. CONTRACTOR'S NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT www.CADdetails.com/info AND ENTER REFERENCE NUMBER 2314-012a.



2314-012a



# NON-VENTED ATTIC DETAIL-OPEN CELL



NOTES:

- 1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
- 2. DO NOT SCALE DRAWING.
- 3. THIS DRAWING IS INTENDED FOR USE BY ARCHITECTS, ENGINEERS, CONTRACTORS, CONSULTANTS AND DESIGN PROFESSIONALS FOR PLANNING PURPOSES ONLY. THIS DRAWING MAY NOT BE USED FOR CONSTRUCTION.
- 4. ALL INFORMATION CONTAINED HEREIN WAS CURRENT AT THE TIME OF DEVELOPMENT BUT MUST BE REVIEWED AND APPROVED BY THE PRODUCT MANUFACTURER TO BE CONSIDERED ACCURATE.
- 5. CONTRACTOR'S NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT www.CADdetails.com/info AND ENTER REFERENCE NUMBER 2314-012.

# APPLICATION DETAILS

NON-VENTED ATTIC DETAIL - OPEN CELL



# TRADITIONAL CEILING DETAIL



- 2. DO NOT SCALE DRAWING.
- 3. THIS DRAWING IS INTENDED FOR USE BY ARCHITECTS, ENGINEERS, CONTRACTORS, CONSULTANTS AND DESIGN PROFESSIONALS FOR PLANNING PURPOSES ONLY. THIS DRAWING MAY NOT BE USED FOR CONSTRUCTION.
- 4. ALL INFORMATION CONTAINED HEREIN WAS CURRENT AT THE TIME OF DEVELOPMENT BUT MUST BE REVIEWED AND APPROVED BY THE PRODUCT MANUFACTURER TO BE CONSIDERED ACCURATE.
- 5. CONTRACTOR'S NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT www.CADdetails.com/info AND ENTER REFERENCE NUMBER 2314-015b.

## APPLICATION DETAILS

TRADITIONAL CEILING DETAIL - TRADITIONAL ATTIC





